



TYPE 1 PREPARATION SEQUENCE:

STEP	DESCRIPTION
1	SET SUBGRADE 10" BELOW FINISH GRADE.
2	REMOVE ALL DEBRIS INCLUDING STUMPS, STICKS, ROOTS AND ROCKS OVER 1" AND DISPOSE OFF SITE. ENGINEER SHALL REVIEW AND APPROVE SUBGRADE PRIOR TO PROCEEDING WITH WORK.
3	PLACE 3" DEPTH TOPSOIL AND SCARIFY TO A DEPTH OF 6".
4	INSTALL 6" DEPTH COMPACTED TOPSOIL TYPE A. COMPACT TO 85% MAXIMUM DRY DENSITY. ENGINEER SHALL REVIEW AND APPROVE TOPSOIL INSTALLATION PRIOR TO PROCEEDING WITH WORK.
5	INSTALL SEED OR 1½" DEPTH MULCH PER SPECIFICATIONS.



**City of
Bellevue**

TITLE:

**PLANTING - STREETSCAPE MEDIANS - TYPE 1
SOIL PREPARATION**

DRAWING #:	PK-IM-06B
SCALE:	N.T.S.
REVISION DATE:	12-2018
DEPARTMENT:	PARKS